



## **DuPont Ion Exchange Resins**

Recommended operating conditions for separate beds in water treatment

### **Introduction**

For optimum performance in water treatment, ion exchange resins should be used within a certain range of operating conditions. Although operating outside the suggested range is possible or even required in specific cases, resin performance data shown in the Product Data Sheets supplied by DuPont are valid within the recommended range only. Contact DuPont Technical Service for assistance when operating outside the suggested ranges to ensure smooth operation. This document presents typical conditions of use for single beds. Other conditions apply to mixed bed units [please refer to [Recommended Operating Conditions for Mixed Bed Ion Exchange Units](#) (Form No. 45-D01127-en)].

### **The Ion Exchange Cycle**

A complete ion exchange cycle consists of the following steps:

- Production (service run)
- Backwash
- Regeneration
- Displacement rinse (slow rinse)
- Fast final rinse

### **Abbreviations**

- CFR: co-flow regeneration
- RFR: reverse-flow regeneration (counter-flow) with air or water hold-down
- BV: bed volume (1 m<sup>3</sup> water per m<sup>3</sup> resin or 7.5 gallons per ft<sup>3</sup> resin)
- SAC: strong acidic cation exchange resin
- WAC: weak acid cation exchange resin
- SBA: strong base anion exchange resin
- WBA: weak base anion exchange resin

### **Packed Beds**

All packed beds are regenerated in reverse flow. There are two types of packed bed systems:

1. Amberpack™ Packed Bed System and floating beds: upflow loading, downflow regeneration
2. Upcore™ Packed Bed System and others: downflow loading, upflow regeneration

Operating conditions for these two types are partially different. Those valid for upflow loading will be indicated by (1), those for downflow loading by (2).

## Operational Conditions – Production

	CFR	RFR <sup>[a]</sup>	Packed Beds
<b>Bed Depth</b> Single beds Layered bed (weak component) Layered bed (strong component)	700 – 2500 mm	1400 – 3000 mm > 600 mm > 800 mm	1400 – 4000 mm > 600 mm > 1000 mm
<b>Specific Flowrate</b> (also called Space Velocity)	6 – 60 BV/h (0.7 – 7 gpm/ft <sup>3</sup> )		
<b>Linear Flowrate</b> (also called Linear Velocity)	limit is $\Delta P$ <sup>[b]</sup> LV > 12 m/h   SAC $\geq$ 25 m/h <sup>[1]</sup>		
<b>Temperature</b>	Ambient water temperature, except for condensate polishing. See individual resin product data sheets for acceptable operational range. Note: operational temperature may impact resin lifetime and/or removal of specific ions, e.g., silica.		

<sup>[a]</sup> With RFR, including packed beds, a higher bed depth produces a higher operating capacity.

<sup>[a]</sup> The limiting parameter for bed depth and linear flowrate is pressure drop.

<sup>[b]</sup> For design purposes a target  $\Delta P$  of 100 kPa for anion should be used. During service, max  $\Delta P$  for cation resins is 300 kPa and 200 kPa for anion resins.

<sup>[1]</sup> Upflow loading, downflow regeneration such as Amberpack™ Packed Bed System

## Operational Conditions – Backwash

### CFR

Backwash is recommended at the end of each service run before regeneration to loosen the resin bed and remove suspended solids that may have accumulated on the resin surface.

### RFR Hold-down systems

Backwash is required only when pressure drop increases due to accumulation of suspended solids or resin particles. Typically, it should be performed every 15 – 20 cycles or when pressure drop exceeds the normal value by more than 50%. It is not recommended to perform backwashes routinely because it could disturb the resin layers. After backwash, a double regeneration must be performed.

### RFR Packed bed systems

Backwashing Amberpack™ Packed Bed Systems and floating beds is not required unless pressure drop exceeds 1.5 times the normal value. When required, backwash is carried out in a separate column after resin transfer. The Upcore™ Packed Bed System has a self-cleaning ability that can be used to migrate suspended solids out.

### Layered beds

Backwash frequency for layered beds is the same as for RFR systems. However, backwash for layered beds should be performed **after regeneration**. Resin densities are more favorable to achieve a clean separation between the weak and the strong component after regeneration than before. Instead of a double regeneration, perform a regeneration before backwashing, and another after backwashing.

### Velocity

The backwash flowrate must be adjusted to achieve a percentage of bed expansion close to the maximum value compatible with the vessel geometry, without losing resin by overflow. The flowrate depends on resin type and on temperature.

## Operational Conditions – Backwash (Cont.)

## Operational Conditions for Strong Acid Cations and Strong Base Anions

### Time

A backwash for 15 – 30 minutes is typically sufficient for CFR systems, unless the resin bed is contaminated with foreign matter. For *initial resin loading*, each new resin charge should be backwashed for at least one hour to make sure that foreign particles and resin fines are washed away.

### Regeneration

	CFR	RFR	Packed Beds
<b>Quantity</b>			
NaCl	90 – 240 g/L	70 – 120 g/L	60 – 100 g/L
HCl	75 – 150 g/L	40 – 80 g/L	40 – 70 g/L
H <sub>2</sub> SO <sub>4</sub>	90 – 240 g/L	60 – 100 g/L	55 – 90 g/L
NaOH	75 – 160 g/L	40 – 80 g/L	40 – 70 g/L
<b>Concentration</b>			
NaCl	10%	10%	10% <sup>[1]</sup> / 2 – 10% <sup>[2]</sup>
HCl	5%	5%	5% <sup>[1]</sup> / 1.5 – 5% <sup>[2]</sup>
H <sub>2</sub> SO <sub>4</sub>	0.8 – 6% depending on Ca content of feed; 0.7% only for any WAC resin, in single column or combined with SAC		
NaOH	4%	2 – 4%	2 – 4%
<b>Regenerant Flowrate</b>	The flowrate derives from regenerant volume and contact time. For Upcore™ Packed Bed Systems, the flowrate (linear velocity) should be enough to guarantee that the resin remains compacted.		
<b>Contact Time</b>	> 20 minutes for all systems (< 60 minutes for H <sub>2</sub> SO <sub>4</sub> )		

<sup>[1]</sup> Upflow loading, downflow regeneration, such as Amberpack™ Packed Bed System

<sup>[2]</sup> Downflow loading, upflow regeneration, such as Upcore™ Packed Bed System

For efficient hydraulic distribution, the volume of regenerant solution should preferably amount to one bed volume or more, and the flowrate should not be too low (≥ 2 BV/h). Lower concentrations may be required for upflow regenerated packed beds marked <sup>2</sup> above to achieve sufficient contact time.

## Operational Conditions – Rinse

### Displacement rinse

	CFR	RFR	Packed beds
<b>Volume</b>			
Cation	2 BV	1.5 BV	1.5 BV
Anion	3 BV	3 BV	2.5 BV
<b>Rinse flowrate</b>	Same as regeneration flowrate		

### Final rinse

	CFR	RFR	Packed beds
<b>Volume</b>			
Cation	2 – 4 BV	0 (recycling) or 2 – 4 BV	0 BV (recycling)
Anion	3 – 8 BV	0 (recycling) or 3 – 8 BV	0 BV (recycling)
<b>Rinse Flowrate</b>	Same as service flowrate or 10 – 30 BV/h		

## Operational Conditions for Weak Acid Cation Resins

### Regeneration

	Dealkalization	Softening	
Quantity	(% operating capacity)	(% total capacity)	
HCl	105 – 110%	110 – 160%	-
H <sub>2</sub> SO <sub>4</sub>	105 – 110%	110 – 160%	-
NaOH	75 – 160 g/L	-	110 – 160%
<b>Concentration</b>			
HCl	2 – 5%	2 – 5%	-
H <sub>2</sub> SO <sub>4</sub>	0.5 – 0.7%	0.5 – 0.7%	-
NaOH	-	-	2 – 4%
<b>Regenerant flowrate</b>			
HCl	2 – 4 BV/h	-	-
H <sub>2</sub> SO <sub>4</sub>	6 – 40 BV/h	6 – 40 BV/h	-
NaOH			2 – 4 BV/h
<b>Displacement Rinse</b>		2 BV at regeneration flowrate	
<b>Fast Rinse</b>		4 – 8 BV at service flowrate	
<b>Contact Time</b>		> 20 minutes for all systems (< 60 minutes for H <sub>2</sub> SO <sub>4</sub> )	

## Operational Conditions for Weak Base Anion Resins

### Regeneration

	Demineralization (% ionic load)
<b>Quantity</b>	
NaOH	115%*
NH <sub>3</sub>	150%
Na <sub>2</sub> CO <sub>3</sub>	200%
<b>Concentration</b>	
NaOH	2 – 4%
NH <sub>3</sub>	2 – 6%
Na <sub>2</sub> CO <sub>3</sub>	5 – 8%
<b>Regenerant Flowrate</b>	
The flowrate derives from regenerant volume and contact time	
<b>Displacement Rinse</b>	
2 BV at regeneration flowrate	
<b>Fast Rinse</b>	
4 – 8 BV at service flowrate	
<b>Contact Time</b>	
> 30 minutes for all regenerants	

\* Increasing NaOH dose to a minimum of 130% stoichiometry is critical for protecting the WBA resin from organic matter fouling when overrunning the resin or for achieving lower total organic carbon (TOC) values in the treated water.

Have a question? Contact us at:

[www.dupont.com/water/contact-us](http://www.dupont.com/water/contact-us)

All information set forth herein is for informational purposes only. This information is general information and may differ from that based on actual conditions. Customer is responsible for determining whether products and the information in this document are appropriate for Customer's use and for ensuring that Customer's workplace and disposal practices are in compliance with applicable laws and other government enactments. The product shown in this literature may not be available for sale and/or available in all geographies where DuPont is represented. The claims made may not have been approved for use in all countries. Please note that physical properties may vary depending on certain conditions and while operating conditions stated in this document are intended to lengthen product lifespan and/or improve product performance, it will ultimately depend on actual circumstances and is in no event a guarantee of achieving any specific results. DuPont assumes no obligation or liability for the information in this document. References to "DuPont" or the "Company" mean the DuPont legal entity selling the products to Customer unless otherwise expressly noted. NO WARRANTIES ARE GIVEN; ALL IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY EXCLUDED. No freedom from infringement of any patent or trademark owned by DuPont or others is to be inferred.

DuPont™, the DuPont Oval Logo, and all trademarks and service marks denoted with ™, SM or ® are owned by affiliates of DuPont de Nemours Inc. unless otherwise noted. © 2020 DuPont.

